



# Kinetic Seesaw Installation Instruction




150 kilogram



3456 x 320 x 1000 (mm)



SS90018\_19022020







3 ..... Obstacle free zone

Bumper options

4




5 ..... Foundation option 1:  
Surface mounted







Foundation option 2:  
Concrete pours


8




10 ..... Open service hatch
















or











## Open the servicehatch

\* Find more information about the computer in the KineticSeesaw User Manual

9

